

Audio Equalizer

DSP Final Project

Youssef Amr ElKady 7651 Group 2 Section 1

Ahmed Hany Ibrahim 7905 Group 1 Section 2

Code:

```
classdef Audio_Equalizer < matlab.apps.AppBase
```

```
% Properties that correspond to app components
```

```
properties (Access = public)
```

UIFigure	matlab.ui.Figure
Panel	matlab.ui.container.Panel
TimeDomainPanel	matlab.ui.container.Panel
AfterLabel_3	matlab.ui.control.Label
BeforeLabel_3	matlab.ui.control.Label
UIAxes2	matlab.ui.control.UIAxes
UIAxes	matlab.ui.control.UIAxes
gain_20k	matlab.ui.control.Slider
KHZSlider_4Label	matlab.ui.control.Label
gain_14k	matlab.ui.control.Slider
KHZSlider_3Label	matlab.ui.control.Label
gain_12k	matlab.ui.control.Slider
KHZSlider_2Label	matlab.ui.control.Label
gain_6k	matlab.ui.control.Slider
KHZSliderLabel	matlab.ui.control.Label
gain_3k	matlab.ui.control.Slider
HZSlider_5Label	matlab.ui.control.Label
gain_1005	matlab.ui.control.Slider
HZSlider_4Label	matlab.ui.control.Label
gain_610	matlab.ui.control.Slider
HZSlider_3Label	matlab.ui.control.Label
gain_300	matlab.ui.control.Slider
HZSlider_2Label	matlab.ui.control.Label
gain_170	matlab.ui.control.Slider
HZSliderLabel	matlab.ui.control.Label
FreuquencyDomainPanel	matlab.ui.container.Panel
BeforeLabel_2	matlab.ui.control.Label
AfterLabel	matlab.ui.control.Label
PhaseLabel	matlab.ui.control.Label
MagnitudeLabel	matlab.ui.control.Label
UIAxes5	matlab.ui.control.UIAxes
UIAxes6	matlab.ui.control.UIAxes
UIAxes4	matlab.ui.control.UIAxes
UIAxes3	matlab.ui.control.UIAxes
FrequencyBandGainsPanel	matlab.ui.container.Panel
SoundhalfnewFSButton	matlab.ui.control.Button
SounddoublenewFSButton	matlab.ui.control.Button
ApplynewfiltersButton	matlab.ui.control.Button
ResetButton	matlab.ui.control.Button
PlotButton	matlab.ui.control.Button
FiltertoPlotDropDown	matlab.ui.control.DropDown
FiltertoPlotDropDownLabel	matlab.ui.control.Label
samplingrateEditField	matlab.ui.control.EditField
samplingrateEditFieldLabel	matlab.ui.control.Label
SaveButton	matlab.ui.control.Button
StartButton	matlab.ui.control.Button

```

Filter_typeButtonGroup    matlab.ui.container.ButtonGroup
IIRButton                 matlab.ui.control.RadioButton
FIRButton                 matlab.ui.control.RadioButton
locationEditField         matlab.ui.control.EditField
locationEditFieldLabel    matlab.ui.control.Label
browseButton              matlab.ui.control.Button
end

```

```

properties (Access = private)
    y % resampled wave
    fir_order = 40
    iir_order = 4
    fs % sampling frequency
    t % time
    fm % frequency/2
    fo % sampling rate output
    Ns % number of samples
    bandgains = ones(1,9); % gains of each band
    newfs % inputted sampling rate
    new_signal % Description
end

```

```

% Callbacks that handle component events
methods (Access = private)

```

```

% Button pushed function: browseButton
function browseButtonPushed(app, event)
    [FileName,FilePath]=uigetfile({'*.wav'});
    fullPath = [FilePath FileName];
    app.locationEditField.Value = fullPath;
    [app.y,app.fs] = audioread(app.locationEditField.Value);
    %disp(app.fs);
    app.y = app.y(:,1);
    app.y = transpose(app.y);
    app.Ns = length(app.y);
    app.t = linspace(0, app.Ns/app.fs, app.Ns);
    app.fm = app.fs/2;

```

```

end

```

```

% Button pushed function: StartButton
function StartButtonPushed(app, event)

```

```

    gains = [app.gain_170.Value app.gain_300.Value app.gain_610.Value
app.gain_1005.Value app.gain_3k.Value app.gain_6k.Value app.gain_12k.Value
app.gain_14k.Value app.gain_20k.Value];
    app.bandgains = db2mag(gains);

    freq = [0,170,300,610,1005,3000,6000,12000,14000,20000];
    x = str2double(app.FiltertoPlotDropDown.Value);

```

```

    if app.Filter_typeButtonGroup.SelectedObject == app.IIRButton

```

```

        if x == 1
            [b, a] = butter(app.iir_order, 170/(app.fs/2), 'low');
        else
            [b, a] = butter(app.iir_order, [freq(x)
freq(x+1)]/(app.fs/2), 'bandpass');
        end
        type = ['IIR'];

    else
        if x == 1
            b = fir1(app.fir_order, 170/(app.fs/2), 'low');
        else
            b = fir1(app.fir_order, [freq(x)
freq(x+1)]/(app.fs/2), 'bandpass');
        end

        a = 1;
        type = ['FIR'];

    end

    title1 = ['Gain and Phase response of ', num2str(freq(x)), ' - ',
num2str(freq(x+1)), ' Hz filter'];
    title2 = ['Impulse response of ', num2str(freq(x)), ' - ',
num2str(freq(x+1)), ' Hz filter'];
    title3 = ['Step response of ', num2str(freq(x)), ' - ',
num2str(freq(x+1)), ' Hz filter'];
    title4 = ['Zeros and Poles of ', num2str(freq(x)), ' - ',
num2str(freq(x+1)), ' Hz filter'];
    title5 = ['Time Domain signal with (', num2str(freq(x)), ' - ',
num2str(freq(x+1)), ' Hz) ', type, ' filter'];
    title6 = ['Magnitude of filtered signal in frequency domain'];
    title7 = ['Phase of filtered signal in frequency domain'];

    figure;
    freqz(b, a);
    title(title1);

    figure;
    subplot(2,2,1);
    impz(b,a);
    title(title2);
    subplot(2,2,2);
    stepz(b,a);
    title(title3);

    [z,p, k] = tf2zpk(b,a);
    subplot(2,2,[3,4]);
    zplane(z,p);
    title(title4);

```

```

        filteredSignal = app.bandgains(x) * filter(b,a,app.y);
        figure;
        subplot(3,1,1)
        plot(app.t,filteredSignal);
        title(title5);
        xlabel('Time in seconds');
        ylabel('Amplitude');

        subplot(3,1,2);
        fmag = abs(fftshift(fft(filteredSignal))/app.fs);
        f_xaxis = linspace(-app.fs/2,app.fs/2,app.Ns);
        plot(f_xaxis,fmag); %filtered signal in frequency domain
        title(title6);
        xlabel('Frequency (Hz)');
        ylabel('Magnitude');

        phase = angle(fftshift(fft(filteredSignal)));
        subplot(3,1,3)
        plot(f_xaxis,phase);
        title(title7);
        xlabel('Frequency (Hz)');
        ylabel('Phase');

        %fvtool(b, a);

    end

    % Callback function
    function samplingrateEditFieldValueChanged(app, event)

    end

    % Button pushed function: ResetButton
    function ResetButtonPushed(app, event)
        app.bandgains = ones(1,9);
        app.gain_170.Value = 0;
        app.gain_300.Value = 0;
        app.gain_610.Value = 0;
        app.gain_1005.Value = 0;
        app.gain_3k.Value = 0;
        app.gain_6k.Value = 0;
        app.gain_12k.Value = 0;
        app.gain_14k.Value = 0;
        app.gain_20k.Value = 0;
    end

    % Button pushed function: PlotButton
    function PlotButtonPushed(app, event)

```

```

    %Time Domain
    plot(app.UIAxes, app.t, app.y) % elly taht 3la el shemal
    t_new =
linspace(0, length(app.new_signal)/app.newfs, length(app.new_signal));
    plot(app.UIAxes2, t_new, app.new_signal); % elly fo2 3la el yemin

    %Frequency Domain
    L1 = length(app.y);
    L2 = length(app.new_signal);
    f_axis1 = linspace(-app.fs/2, app.fs/2, L1);
    f_axis2 = linspace(-app.newfs/2, app.newfs/2, L2);

    %Frequency Magnitude
    fmag1 = abs(fftshift(fft(app.y))/app.fs); %we divide by L1 to normalize
    plot(app.UIAxes4, f_axis1, fmag1); % 3la el yemin taht khales

    % we divide by L2 to normalize
    fmag2 = abs(fftshift(fft(app.new_signal))/app.newfs);
    plot(app.UIAxes3, f_axis2, fmag2); % 3la el shemal taht khales

    %Frequency Phase
    fphase1 = angle(fftshift(fft(app.y)));
    plot(app.UIAxes6, f_axis1, fphase1); % 3la el yemin taht khales
    fphase2 = angle(fftshift(fft(app.new_signal)));
    plot(app.UIAxes5, f_axis2, fphase2); % 3la el shemal taht khales

end

% Button pushed function: ApplynewfiltersButton
function ApplynewfiltersButtonPushed(app, event)
    gains = [app.gain_170.Value app.gain_300.Value app.gain_610.Value
app.gain_1005.Value app.gain_3k.Value app.gain_6k.Value app.gain_12k.Value
app.gain_14k.Value app.gain_20k.Value];
    app.bandgains = db2mag(gains);
    app.newfs = app.samplingrateEditField.Value();
    freq = [0, 170, 300, 610, 1005, 3000, 6000, 12000, 14000, 20000];
    app.new_signal = zeros(1, length(app.y));

    if app.Filter_typeButtonGroup.SelectedObject == app.FIRButton
        for x = 1:9
            if x==1
                b = fir1(app.fir_order, 170/app.fm);
            else
                b = fir1(app.fir_order, [freq(x)
freq(x+1)]/app.fm, 'bandpass');
            end
            filteredSignal = filter(b, 1, app.y); %filtered signal in time
domain
            app.new_signal = app.new_signal +
(filteredSignal*app.bandgains(x));
        end
    else
        for x = 1:9

```

```

        if x==1
            [b,a] = butter(app.iir_order,170/app.fm);
        else
            [b,a] = butter(app.iir_order,[freq(x)
freq(x+1)]/app.fm,'bandpass');
        end

        filteredSignal = filter(b,a,app.y);
        app.new_signal = app.new_signal +
(filteredSignal*app.bandgains(x));
    end
end
if strcmpi(app.newfs,'Enter new Sampling rate') == 1
    app.newfs = app.fs;
else
    app.newfs = str2double(app.newfs);
end
%app.new_signal = resample(app.new_signal,app.newfs,app.fs);

end

% Button pushed function: SaveButton
function SaveButtonPushed(app, event)
    audiowrite("output_file_half.wav",app.new_signal, app.newfs/2);
    audiowrite("output_file_double.wav",app.new_signal, app.newfs*2);

end

% Button pushed function: SounddoublenewFSButton
function SounddoublenewFSButtonPushed(app, event)
    sound(app.new_signal, app.newfs*2);
    half_t = linspace(0,length(app.y)/(app.newfs*2),length(app.y));
    figure;
    subplot(2,1,1);
    plot(half_t,app.y);
    title("Output signal for double inputted FS");
    %Frequency Domain
    L1 = length(app.y);
    f_xaxis1 = linspace(-app.newfs,app.newfs,L1);
    %Frequency Magnitude
    fmag1 = abs(fftshift(fft(app.y))/app.newfs*2); %we divide by L1 to
normalize
    subplot(2,1,2);
    plot(f_xaxis1,fmag1);
    title("magnitude of Double fs");
end

% Button pushed function: SoundhalfnewFSButton
function SoundhalfnewFSButtonPushed(app, event)
    sound(app.new_signal, app.newfs/2);
    Double_t = linspace(0,length(app.y)/(app.newfs/2),length(app.y));
    figure;
    subplot(2,1,1);

```

```

plot(Double_t,app.y);
title("Output signal for half inputted FS");
%Frequency Domain
L1 = length(app.y);
f_xaxis1 = linspace(-app.newfs/4,app.newfs/4,L1);

%Frequency Magnitude
fmag1 = abs(fftshift(fft(app.y))/app.newfs/2); %we divide by L1 to
normalize
subplot(2,1,2);
plot(f_xaxis1,fmag1);
title("magnitude of half fs");

end
end

% Component initialization
methods (Access = private)

% Create UIFigure and components
function createComponents(app)

    % Create UIFigure and hide until all components are created
    app.UIFigure = uifigure('Visible', 'off');
    app.UIFigure.Color = [0.902 0.902 0.902];
    app.UIFigure.Position = [100 100 1103 826];
    app.UIFigure.Name = 'MATLAB App';

    % Create browseButton
    app.browseButton = uibutton(app.UIFigure, 'push');
    app.browseButton.ButtonPushedFcn = createCallbackFcn(app,
@browseButtonPushed, true);
    app.browseButton.Position = [290 787 100 22];
    app.browseButton.Text = 'browse';

    % Create locationEditFieldLabel
    app.locationEditFieldLabel = uilabel(app.UIFigure);
    app.locationEditFieldLabel.HorizontalAlignment = 'right';
    app.locationEditFieldLabel.Position = [18 787 47 22];
    app.locationEditFieldLabel.Text = 'location';

    % Create locationEditField
    app.locationEditField = uieditfield(app.UIFigure, 'text');
    app.locationEditField.Position = [80 787 183 22];

    % Create Filter_typeButtonGroup
    app.Filter_typeButtonGroup = uibuttongroup(app.UIFigure);
    app.Filter_typeButtonGroup.Title = 'Filter_type';
    app.Filter_typeButtonGroup.Position = [657 738 123 82];

    % Create FIRButton
    app.FIRButton = uiradiobutton(app.Filter_typeButtonGroup);
    app.FIRButton.Text = 'FIR';
    app.FIRButton.Position = [11 36 58 22];
    app.FIRButton.Value = true;

```



```

% Create IIRButton
app.IIRButton = uiradiobutton(app.Filter_typeButtonGroup);
app.IIRButton.Text = 'IIR';
app.IIRButton.Position = [11 14 65 22];

% Create StartButton
app.StartButton = uibutton(app UIFigure, 'push');
app.StartButton.ButtonPushedFcn = createCallbackFcn(app,
@StartButtonPushed, true);
app.StartButton.Position = [804 787 100 22];
app.StartButton.Text = 'Start';

% Create SaveButton
app.SaveButton = uibutton(app UIFigure, 'push');
app.SaveButton.ButtonPushedFcn = createCallbackFcn(app,
@SaveButtonPushed, true);
app.SaveButton.Position = [804 752 100 22];
app.SaveButton.Text = 'Save';

% Create samplingrateEditFieldLabel
app.samplingrateEditFieldLabel = uilabel(app UIFigure);
app.samplingrateEditFieldLabel.HorizontalAlignment = 'right';
app.samplingrateEditFieldLabel.Position = [411 787 78 22];
app.samplingrateEditFieldLabel.Text = 'sampling rate';

% Create samplingrateEditField
app.samplingrateEditField = uieditfield(app UIFigure, 'text');
app.samplingrateEditField.Position = [504 787 141 22];
app.samplingrateEditField.Value = 'Enter new Sampling rate';

% Create FiltertoPlotDropDownLabel
app.FiltertoPlotDropDownLabel = uilabel(app UIFigure);
app.FiltertoPlotDropDownLabel.HorizontalAlignment = 'right';
app.FiltertoPlotDropDownLabel.Position = [432 752 76 22];
app.FiltertoPlotDropDownLabel.Text = {'Filter to Plot'; ''};

% Create FiltertoPlotDropDown
app.FiltertoPlotDropDown = uidropdown(app UIFigure);
app.FiltertoPlotDropDown.Items = {'0-170 HZ', '170-300 HZ', '300-610 HZ',
'610-1005 HZ', '1005-3000 HZ', '3-6 KHZ', '6-12 KHZ', '12-14 KHZ', '14-20 KHZ'};
app.FiltertoPlotDropDown.ItemsData = {'1', '2', '3', '4', '5', '6', '7',
'8', '9'};
app.FiltertoPlotDropDown.Position = [523 752 100 22];
app.FiltertoPlotDropDown.Value = '3';

% Create Panel
app.Panel = uipanel(app UIFigure);
app.Panel.BorderType = 'none';
app.Panel.BackgroundColor = [0.5098 0.6 0.8392];
app.Panel.Position = [1 1 1103 737];

% Create FrequencyBandGainsPanel
app.FrequencyBandGainsPanel = uipanel(app.Panel);
app.FrequencyBandGainsPanel.BorderType = 'none';

```

```

app.FrequencyBandGainsPanel.TitlePosition = 'centertop';
app.FrequencyBandGainsPanel.Title = 'Frequency Band Gains';
app.FrequencyBandGainsPanel.BackgroundColor = [0.8078 0.851 0.8118];
app.FrequencyBandGainsPanel.FontWeight = 'bold';
app.FrequencyBandGainsPanel.FontSize = 22;
app.FrequencyBandGainsPanel.Position = [1 432 771 306];

% Create PlotButton
app.PlotButton = uibutton(app.FrequencyBandGainsPanel, 'push');
app.PlotButton.ButtonPushedFcn = createCallbackFcn(app,
@PlotButtonPushed, true);
app.PlotButton.FontSize = 18;
app.PlotButton.FontWeight = 'bold';
app.PlotButton.Position = [503 20 100 29];
app.PlotButton.Text = 'Plot';

% Create ResetButton
app.ResetButton = uibutton(app.FrequencyBandGainsPanel, 'push');
app.ResetButton.ButtonPushedFcn = createCallbackFcn(app,
@ResetButtonPushed, true);
app.ResetButton.FontSize = 14;
app.ResetButton.Position = [622 22 132 29];
app.ResetButton.Text = 'Reset';

% Create ApplynewfiltersButton
app.ApplynewfiltersButton = uibutton(app.FrequencyBandGainsPanel,
'push');
app.ApplynewfiltersButton.ButtonPushedFcn = createCallbackFcn(app,
@ApplynewfiltersButtonPushed, true);
app.ApplynewfiltersButton.FontSize = 14;
app.ApplynewfiltersButton.Position = [24 21 136 29];
app.ApplynewfiltersButton.Text = 'Apply new filters';

% Create SounddoublenewFSButton
app.SounddoublenewFSButton = uibutton(app.FrequencyBandGainsPanel,
'push');
app.SounddoublenewFSButton.ButtonPushedFcn = createCallbackFcn(app,
@SounddoublenewFSButtonPushed, true);
app.SounddoublenewFSButton.Position = [178.5 21 139 28];
app.SounddoublenewFSButton.Text = 'Sound double new FS';

% Create SoundhalfnewFSButton
app.SoundhalfnewFSButton = uibutton(app.FrequencyBandGainsPanel, 'push');
app.SoundhalfnewFSButton.ButtonPushedFcn = createCallbackFcn(app,
@SoundhalfnewFSButtonPushed, true);
app.SoundhalfnewFSButton.Position = [347 22 139 28];
app.SoundhalfnewFSButton.Text = 'Sound half new FS';

% Create FreuquencyDomainPanel
app.FreuquencyDomainPanel = uipanel(app.Panel);
app.FreuquencyDomainPanel.BorderType = 'none';
app.FreuquencyDomainPanel.TitlePosition = 'centertop';
app.FreuquencyDomainPanel.Title = 'Freuquency Domain';
app.FreuquencyDomainPanel.BackgroundColor = [0.8118 0.851 0.8118];
app.FreuquencyDomainPanel.FontWeight = 'bold';

```

```

app.FrequencyDomainPanel.FontSize = 22;
app.FrequencyDomainPanel.Position = [1 1 771 432];

% Create UIAxes3
app.UIAxes3 = uiaxes(app.FrequencyDomainPanel);
title(app.UIAxes3, 'Title')
xlabel(app.UIAxes3, 'time(s)')
ylabel(app.UIAxes3, 'magnitude')
app.UIAxes3.XTickLabelRotation = 0;
app.UIAxes3.YTickLabelRotation = 0;
app.UIAxes3.ZTickLabelRotation = 0;
app.UIAxes3.Position = [24 199 267 166];

% Create UIAxes4
app.UIAxes4 = uiaxes(app.FrequencyDomainPanel);
title(app.UIAxes4, 'Title')
xlabel(app.UIAxes4, 'time(s)')
ylabel(app.UIAxes4, 'magnitude')
app.UIAxes4.XTickLabelRotation = 0;
app.UIAxes4.YTickLabelRotation = 0;
app.UIAxes4.ZTickLabelRotation = 0;
app.UIAxes4.Position = [429 193 249 179];

% Create UIAxes6
app.UIAxes6 = uiaxes(app.FrequencyDomainPanel);
xlabel(app.UIAxes6, 'time(s)')
ylabel(app.UIAxes6, 'phase')
app.UIAxes6.XTickLabelRotation = 0;
app.UIAxes6.YTickLabelRotation = 0;
app.UIAxes6.ZTickLabelRotation = 0;
app.UIAxes6.Position = [429 14 247 162];

% Create UIAxes5
app.UIAxes5 = uiaxes(app.FrequencyDomainPanel);
title(app.UIAxes5, {''; ''})
xlabel(app.UIAxes5, 'time(s)')
ylabel(app.UIAxes5, 'phase')
app.UIAxes5.XTickLabelRotation = 0;
app.UIAxes5.YTickLabelRotation = 0;
app.UIAxes5.ZTickLabelRotation = 0;
app.UIAxes5.Position = [25 12 266 164];

% Create MagnitudeLabel
app.MagnitudeLabel = uilabel(app.FrequencyDomainPanel);
app.MagnitudeLabel.HorizontalAlignment = 'center';
app.MagnitudeLabel.FontSize = 18;
app.MagnitudeLabel.Position = [262 371 193 22];
app.MagnitudeLabel.Text = 'Magnitude';

% Create PhaseLabel
app.PhaseLabel = uilabel(app.FrequencyDomainPanel);
app.PhaseLabel.HorizontalAlignment = 'center';
app.PhaseLabel.FontSize = 18;
app.PhaseLabel.Position = [262 162 193 22];
app.PhaseLabel.Text = 'Phase';

```

```

% Create AfterLabel
app.AfterLabel = uilabel(app.FrequencyDomainPanel);
app.AfterLabel.HorizontalAlignment = 'center';
app.AfterLabel.FontSize = 18;
app.AfterLabel.Position = [75 371 193 22];
app.AfterLabel.Text = 'After';

% Create BeforeLabel_2
app.BeforeLabel_2 = uilabel(app.FrequencyDomainPanel);
app.BeforeLabel_2.HorizontalAlignment = 'center';
app.BeforeLabel_2.FontSize = 18;
app.BeforeLabel_2.Position = [468 371 193 22];
app.BeforeLabel_2.Text = 'Before';

% Create HZSliderLabel
app.HZSliderLabel = uilabel(app.Panel);
app.HZSliderLabel.HorizontalAlignment = 'right';
app.HZSliderLabel.VerticalAlignment = 'bottom';
app.HZSliderLabel.Position = [17 495 55 22];
app.HZSliderLabel.Text = {'0-170 HZ'; ''};

% Create gain_170
app.gain_170 = uislider(app.Panel);
app.gain_170.Limits = [-12 12];
app.gain_170.Orientation = 'vertical';
app.gain_170.Position = [29 533 3 150];

% Create HZSlider_2Label
app.HZSlider_2Label = uilabel(app.Panel);
app.HZSlider_2Label.HorizontalAlignment = 'center';
app.HZSlider_2Label.VerticalAlignment = 'bottom';
app.HZSlider_2Label.Position = [82 495 69 22];
app.HZSlider_2Label.Text = {'170-300 HZ'; ''};

% Create gain_300
app.gain_300 = uislider(app.Panel);
app.gain_300.Limits = [-12 12];
app.gain_300.Orientation = 'vertical';
app.gain_300.Position = [108 532 3 150];

% Create HZSlider_3Label
app.HZSlider_3Label = uilabel(app.Panel);
app.HZSlider_3Label.HorizontalAlignment = 'right';
app.HZSlider_3Label.VerticalAlignment = 'bottom';
app.HZSlider_3Label.Position = [164 496 69 22];
app.HZSlider_3Label.Text = {'300-610 HZ'; ''};

% Create gain_610
app.gain_610 = uislider(app.Panel);
app.gain_610.Limits = [-12 12];
app.gain_610.Orientation = 'vertical';
app.gain_610.Position = [190 532 3 150];

% Create HZSlider_4Label

```

```

app.HZSlider_4Label = uilabel(app.Panel);
app.HZSlider_4Label.HorizontalAlignment = 'right';
app.HZSlider_4Label.VerticalAlignment = 'bottom';
app.HZSlider_4Label.Position = [241 496 72 22];
app.HZSlider_4Label.Text = '610-1005HZ';

% Create gain_1005
app.gain_1005 = uislider(app.Panel);
app.gain_1005.Limits = [-12 12];
app.gain_1005.MajorTicks = [-12 -9 -6 -3 0 3 6 9 12];
app.gain_1005.MajorTickLabels = {'-12,', '-9,', '-6,', '-3,', '0,', '3,',
'6,', '9,', '12'};
app.gain_1005.Orientation = 'vertical';
app.gain_1005.MinorTicks = [-12 -11.4 -10.8 -10.2 -9.6 -9 -8.4 -7.8 -7.2
-6.6 -6 -5.4 -4.8 -4.2 -3.6 -3 -2.4 -1.8 -1.2 -0.6 0 0.6 1.2 1.8 2.4 3 3.6 4.2 4.8
5.4 6 6.6 7.2 7.8 8.4 9 9.6 10.2 10.8 11.4 12];
app.gain_1005.Position = [259 532 3 150];

% Create HZSlider_5Label
app.HZSlider_5Label = uilabel(app.Panel);
app.HZSlider_5Label.HorizontalAlignment = 'right';
app.HZSlider_5Label.VerticalAlignment = 'bottom';
app.HZSlider_5Label.Position = [321 496 82 22];
app.HZSlider_5Label.Text = '1005-3000 HZ';

% Create gain_3k
app.gain_3k = uislider(app.Panel);
app.gain_3k.Limits = [-12 12];
app.gain_3k.Orientation = 'vertical';
app.gain_3k.Position = [347 532 3 150];

% Create KHZSliderLabel
app.KHZSliderLabel = uilabel(app.Panel);
app.KHZSliderLabel.HorizontalAlignment = 'right';
app.KHZSliderLabel.VerticalAlignment = 'bottom';
app.KHZSliderLabel.Position = [419 496 47 22];
app.KHZSliderLabel.Text = '3-6KHZ';

% Create gain_6k
app.gain_6k = uislider(app.Panel);
app.gain_6k.Limits = [-12 12];
app.gain_6k.Orientation = 'vertical';
app.gain_6k.Position = [429 532 3 150];

% Create KHZSlider_2Label
app.KHZSlider_2Label = uilabel(app.Panel);
app.KHZSlider_2Label.HorizontalAlignment = 'center';
app.KHZSlider_2Label.VerticalAlignment = 'bottom';
app.KHZSlider_2Label.Position = [490 495 57 22];
app.KHZSlider_2Label.Text = '6-12 KHZ';

% Create gain_12k
app.gain_12k = uislider(app.Panel);
app.gain_12k.Limits = [-12 12];
app.gain_12k.Orientation = 'vertical';

```

```

app.gain_12k.Position = [504 533 3 150];

% Create KHZSlider_3Label
app.KHZSlider_3Label = uilabel(app.Panel);
app.KHZSlider_3Label.HorizontalAlignment = 'right';
app.KHZSlider_3Label.VerticalAlignment = 'bottom';
app.KHZSlider_3Label.Position = [557 496 63 22];
app.KHZSlider_3Label.Text = '12-14 KHZ';

% Create gain_14k
app.gain_14k = uislider(app.Panel);
app.gain_14k.Limits = [-12 12];
app.gain_14k.Orientation = 'vertical';
app.gain_14k.Position = [577 532 3 150];

% Create KHZSlider_4Label
app.KHZSlider_4Label = uilabel(app.Panel);
app.KHZSlider_4Label.HorizontalAlignment = 'right';
app.KHZSlider_4Label.VerticalAlignment = 'bottom';
app.KHZSlider_4Label.Position = [631 496 63 22];
app.KHZSlider_4Label.Text = '14-20 KHZ';

% Create gain_20k
app.gain_20k = uislider(app.Panel);
app.gain_20k.Limits = [-12 12];
app.gain_20k.Orientation = 'vertical';
app.gain_20k.Position = [645 532 3 150];

% Create TimeDomainPanel
app.TimeDomainPanel = uipanel(app.Panel);
app.TimeDomainPanel.TitlePosition = 'centertop';
app.TimeDomainPanel.Title = 'Time Domain';
app.TimeDomainPanel.BackgroundColor = [0.8118 0.851 0.8118];
app.TimeDomainPanel.FontWeight = 'bold';
app.TimeDomainPanel.FontSize = 22;
app.TimeDomainPanel.Position = [793 1 311 737];

% Create UIAxes
app.UIAxes = uiaxes(app.TimeDomainPanel);
title(app.UIAxes, 'Title')
xlabel(app.UIAxes, 'time(s)')
ylabel(app.UIAxes, 'Y')
app.UIAxes.XTickLabelRotation = 0;
app.UIAxes.YTickLabelRotation = 0;
app.UIAxes.ZTickLabelRotation = 0;
app.UIAxes.Position = [27 494 268 160];

% Create UIAxes2
app.UIAxes2 = uiaxes(app.TimeDomainPanel);
title(app.UIAxes2, 'Title')
xlabel(app.UIAxes2, 'time(s)')
ylabel(app.UIAxes2, 'Y')
app.UIAxes2.XTickLabelRotation = 0;
app.UIAxes2.YTickLabelRotation = 0;
app.UIAxes2.ZTickLabelRotation = 0;

```

```

    app.UIAxes2.Position = [10 234 285 173];

    % Create BeforeLabel_3
    app.BeforeLabel_3 = uilabel(app.TimeDomainPanel);
    app.BeforeLabel_3.HorizontalAlignment = 'center';
    app.BeforeLabel_3.FontSize = 18;
    app.BeforeLabel_3.Position = [87 666 193 22];
    app.BeforeLabel_3.Text = 'Before';

    % Create AfterLabel_3
    app.AfterLabel_3 = uilabel(app.TimeDomainPanel);
    app.AfterLabel_3.HorizontalAlignment = 'center';
    app.AfterLabel_3.FontSize = 18;
    app.AfterLabel_3.Position = [88 430 193 22];
    app.AfterLabel_3.Text = 'After';

    % Show the figure after all components are created
    app.UIFigure.Visible = 'on';
end
end

% App creation and deletion
methods (Access = public)

    % Construct app
    function app = Audio_Equalizer

        % Create UIFigure and components
        createComponents(app)

        % Register the app with App Designer
        registerApp(app, app.UIFigure)

        if nargin == 0
            clear app
        end
    end


    % Code that executes before app deletion
    function delete(app)

        % Delete UIFigure when app is deleted
        delete(app.UIFigure)
    end
end
end
end


```

FIR


Fs = 48 KHZ (original):






FIR Half






FIR Double






Filter 0- 170 Hz:






Filter 170- 300 Hz:






Filter 300-610 Hz:






Filter 610-1005 Hz:






Filter 1005 – 3000 Hz:






Filter 3000 – 6000 Hz:






Filter 6000 – 12000 Hz:



Filter 12000 – 14000 Hz:




Filter 14000 – 20000 Hz:




IIR


Fs = 48 KHZ (original):






IIR Half






IIR Double






Filter 0 – 170 Hz:






Filter 170 – 300 Hz:






Filter 300 – 610 Hz:






Filter 610 – 1005 Hz:




Filter 1005 – 3000 Hz:






Filter 3000 – 6000 Hz:



Filter 6000 – 12000 Hz:



Filter 12000– 14000 Hz:



Filter 14000– 20000 Hz:

